

# SMART TOOL-SETTER TIGHTENING FIXTURES



Rotate the handle to lock the tool positively.

Up to  
20%  
off!

Pull the Knob to unlock the Tool-Setter and rotate to position. Release the knob to lock in place.



Left Hand



Vertical



Right Hand

## Toolholder Taper Protected From Chips & Scratches

- Multi-Functional
- Quick Lock & Setting
- Multi-Position Setting
- Heavy Duty Construction
- Teflon Based Xylan Coating
- Precise Quality & Workmanship
- Holds CAT, BT or HSK Toolholders

UPC #	Description	Tool Size	List Price	Promo
36000-Z25A1	DSTSCH-030	BT-30	411.76	<b>\$329</b>
36001-Z25A1	DSTSCH-040	BT-40 CAT-40	411.76	<b>\$329</b>
36002-Z25A1	DSTSCH-050	BT-50 CAT-50	491.66	<b>\$393</b>
36003-Z25A1	DSTSHSK-063	HSK-063	558.70	<b>\$447</b>
36004-Z25A1	DSTSHSK-100	HSK-100	593.61	<b>\$475</b>

## Mounting

### Mounting Holes



Mount the Smart Tool-Setter on a solid workbench. Use the 4 holes provided on the base to bolt down the Smart Tool-Setter.

## Holder Loading



Indexing knob



Locking knob

Put holder in while locking knob is in unlocked position. Rotate locking knob to locked position to lock holder on the V-groove located on the diameter of the holder. Locking knob positively locks the tool in and does not allow tool to come out of place.

## Application

The Smart Tool-Setter's precise and heavy duty construction make the tool-setter very rigid and able to endure extreme forces without causing any damage to tools or the Smart Tool-Setter. The multi-functioning and positioning of the Smart Tool-Setter allow the operator to switch quickly and easily from one operation to another without loss of time.

### Small Tool Change



Endmills can be easily, quickly, and precisely set with the Smart Tool-Setter.

### Large Tool Change



Large tools can be mounted or removed with the Smart Tool-Setter.

## Positioning



Vertical



Horizontal Left Hand



Horizontal Right Hand

Pull the indexing knob to unlock, turn into a new position, and release the indexing knob to lock.

### Pull Stud Change



Pull Studs can be quickly and easily changed using the Smart Tool-Setter.